

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
<ul style="list-style-type: none">• With the ignition switch in ACC or ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed.• SRS warning light is always light up even when ignition switch is in the LOCK position.	<ul style="list-style-type: none">• SRS warning light circuit (Always lights up when ignition switch is in LOCK position.)	DI-143
<ul style="list-style-type: none">• With the ignition switch in ACC or ON position, the SRS warning light does not light up.	<ul style="list-style-type: none">• SRS warning light circuit (Does not light up when ignition switch is turned to ACC or ON.)	DI-147
<ul style="list-style-type: none">• DTC is not displayed.• SRS warning light is always light up at the time of DTC check procedure.• DTC is displayed without TC and E1 terminal connection.	<ul style="list-style-type: none">• TC terminal circuit	DI-151