

STEERING WHEEL PAD AND SPIRAL CABLE REMOVAL

RS0JK-01

HINT:

For step 1 to 4, refer to [page SR-3](#).

1. REMOVE STEERING WHEEL PAD
2. REMOVE STEERING WHEEL
3. REMOVE UPPER AND LOWER COLUMN COVERS
4. REMOVE SPIRAL CABLE