

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the front passenger airbag assembly, instrument panel or instrument panel reinforcement.

- If the airbag has been deployed.
- If the front passenger airbag assembly has been found to be faulty in troubleshooting.
- If the front passenger airbag assembly, instrument panel or instrument panel reinforcement has been found to be faulty during the check in items (See page RS-24).
- If the front passenger airbag assembly has been dropped.

CAUTION:

For replacement of the front passenger airbag assembly, see page RS-23 and RS-32. Be sure to follow the correct procedure.