Power Source | 4WD | Seat Belt Warning | Seat Heater

1 | 2 | 3 | 4

W
W
W
4
AM1
AM2
ACC
IG1
ST1
IG2
ST2
2
B-Y
I14
IGNITION SW
1 (A)
1 (B)
FL AM1
60A
F5
FUSIBLE LINK
BOX
[Gasoline, Diesel]
BATTERY
B
C
B-Y
10A
TURN-
GAUGE
R-L
J9
JUNCTION
CONNECTOR
J8
JUNCTION
CONNECTOR
F14
4WD DETECTION
SW
Y-L
Y-R
V5
VSV (For 2WD)
V6
VSV (For 4WD)
W-B
J7
JUNCTION
CONNECTOR
S4
SEAT BELT
WARNING RELAY
LG-B
LG
C8 (D), C9 (C)
SEAT BELT
WARNING LIGHT
[COMB. METER]
B6
BUCKLE SW
(Driver's)
L
BM1
15A
SEAT
HEATER
L-B
S5
SEAT HEATER SW
(DRIVER'S)
S6
SEAT HEATER SW
(PASSENGER'S)
H
L
W-B
L-W
L-R
BW1
BL1
S13
SEAT HEATER
(Driver's,
Seat Back)
S12
SEAT HEATER
(Driver's,
Seat Cushion)
S14
SEAT HEATER
(Passenger's,
Seat Cushion)
J6
JUNCTION
CONNECTOR
H
I

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

B = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

C = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

H = Located on instrument panel left (LHD)
= *Monté á gauche du tableau de bord (LHD)*
= Angebracht an dem linken Teil der instrumententafel (LHD)
= *Situado al lado derecho del tablero de instrumentos (LHD)*

I = Located on instrument panel right (LHD)
= *Monté sur le côte droit du tableau de bord (LHD)*
= Angebracht an der richten Seite des instrumentenbretts (LHD)
= *Situado en el lado izquierdo del panel instrumental (LHD)*