Power Source

Light Reminder

Rear Fog Light

1 2 3 4 5

(Gasoline)
W
W (*2) (Diesel)
W (Ex. *2) (Diesel)
W (LHD)
(LHD)
(RHD)
L-R
B-Y
R-L
R-Y
R-G
G-W
G-R
G
GR
R
V
W-B
G-R

I14 IGNITION SW
ACC
IG1
ST1
IG2
ST2
AM1
AM2

15A RADIO-CIG
10A TURN-GAUGE (LHD)
10A TURN-GAUGE (RHD)
15A TAIL (Ex. Germany)
10A TAIL RH (Germany)
J7 JUNCTION CONNECTOR
J3 JUNCTION CONNECTOR
J9 JUNCTION CONNECTOR
J5 JUNCTION CONNECTOR
J4 JUNCTION CONNECTOR
J6 JUNCTION CONNECTOR
L2 LIGHT REMINDER BUZZER
TAILLIGHT RELAY (RHD)
TAILLIGHT RELAY (LHD)
To Light Control SW "T" (8-4)
To Day Time Running Light Relay (Norway, Sweden) (To Light Control SW "T" (Ex. Norway, Sweden)(7-4)
Door Courtesy SW Front LH (LHD) Front RH (RHD) (9-2)(10-3)

(Norway, Sweden, Germany)
R7 REAR FOG LIGHT SHORT PIN (Ex. Norway, Sweden, Germany)
From Headlight (5-3)
To Diode (For Rear Fog Light) (Ex. Norway, Sweden) (5-2)(17-2)
To Day Time Running Light Relay (Norway, Sweden) (6-2)
15A ECU-B
REAR FOG LIGHT RELAY
R6 REAR FOG LIGHT SW
BP 2
J7 JUNCTION CONNECTOR
R17 REAR FOG LIGHT LH (REAR COMB. LIGHT LH)
R18 REAR FOG LIGHT RH (REAR COMB. LIGHT RH)

7.5A DOME
J5 JUNCTION CONNECTOR
To Diode (For Rear Fog Light) (5-2)(18-3)
R-Y (TRZ) R-W (U.K. ZL) R-L (Ex. U.K. ZL)

F5 FUSIBLE LINK BOX (Gasoline)
F5 FUSIBLE LINK BOX (Diesel)
FL AM1 60A
FL ALT 100A
FL AM1 60A (LHD)
FL AM1 80A *1
FL AM1 50A *2
Ex. *2
BATTERY

*1 RHD for Europe, and all models Ex. *2
*2 RHD for General, and Australia M/T Model w/o conversion package (for Telecom)
*3 Australia w/o conversion package (for Telecom)
*4 All models Ex. *3

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

B = Located on engine block
Monté sur le bloc-moteur
Angebracht auf dem Motor
Situado en el bloque motor

C = Located on left side member
Monté sur le côté gauche du longeron
Angebracht an der linken Seite der Kreuzstrebe
Situado en el lado izquierdo del travesaño

I = Located on instrument panel right (LHD)
Monté sur le côte droit du tableau de bord (LHD)
Angebracht an der richten Seite des instrumentenbretts (LHD)
Situado en el lado izquierdo del panel instrumental (LHD)

I = Located on instrument panel left (RHD)
Monté à gauche du tableau de bord (RHD)
Angebracht an dem linken Teil der instrumententafel (RHD)
Situado al lado derecho del tablero de instrumentos (RHD)

J = Located on right rear fender
Monté sur l'aile arriere droite
Angebracht am rechten hinteren Kotflügel
Situado en el guardabarros trasero derecho