



Power Source



Door Lock

- *1 RHD for Europe, and all models Ex. *2
 *2 RHD for General, and Australia M/T model w/o conversion package (for Telecom)
 *3 Australia w/o conversion package (for Telecom)
 *4 All models Ex. *3

F5
FUSIBLE LINK
BOX (Gasoline)F5
FUSIBLE LINK
BOX (Diesel)

BATTERY

- △ = Located on instrument panel left (RHD)
 = Monté à gauche du tableau de bord (RHD)
 = Angebracht an dem linken Teil der instrumententafel (RHD)
 = Situado al lado derecho del tablero de instrumentos (RHD)

- △ = Located on engine block
 = Monté sur le bloc-moteur
 = Angebracht auf dem Motor
 = Situado en el bloque motor

- △ = Located on left side member
 = Monté sur le côté gauche du longeron
 = Angebracht an der linken Seite der Kreuzstrebe
 = Situado en el lado izquierdo del travesaño

- △ = Located on instrument panel left (LHD)
 = Monté à gauche du tableau de bord (LHD)
 = Angebracht an dem linken Teil der instrumententafel (LHD)
 = Situado al lado derecho del tablero de instrumentos (LHD)

- △ = Located on instrument panel right (RHD)
 = Monté sur le côté droit du tableau de bord (RHD)
 = Angebracht an der rechten Seite des instrumentenbretts (RHD)
 = Situado en el lado izquierdo del panel instrumental (RHD)

- △ = Located on instrument panel right (LHD)
 = Monté sur le côté droit du tableau de bord (LHD)
 = Angebracht an der rechten Seite des instrumentenbretts (LHD)
 = Situado en el lado izquierdo del panel instrumental (LHD)

