Power Source

Headlight Cleaner (Europe LHD)

Rear Wiper and Washer

Front Wiper and Washer

1 2 3 4

= Located on instrument panel left (RHD)
= *Monté à gauche du tableau de bord (RHD)*
= Angebracht an dem linken Teil der instrumententafel (RHD)
= *Situado al lado derecho del tablero de instrumentos (RHD)*

= Located on right rear fender
= *Monté sur l'aile arriere droite*
= Angebracht am rechten hinteren Kotflügel
= *Situado en el guardabarros trasero derecho*

*1 RHD for Europe, and all models Ex. *2
*2 RHD for General, and Australia M/T model w/o conversion package (for Telecom)
*3 Australia w/o conversion package (for Telecom)
*4 All models Ex. *3

I14 IGNITION SW

F5 FUSIBLE LINK BOX (Gasoline)

F5 FUSIBLE LINK BOX (Diesel)

60A AM1

100A ALT

60A AM1 (LHD)
80A AM1 (*1)
50A AM1 (*2)

BATTERY

H6 HEADLIGHT CLEANER MOTOR

H12 HEADLIGHT CLEANER RELAY

H2 HEADLIGHT CLEANER SW

To Daytime Running Light Relay (6-3)

FUSIBLE LINK BOX

20A WIPER (LHD)

20A WIPER (RHD)

J5 JUNCTION CONNECTOR

R22 REAR WASHER MOTOR

W5 WASHER MOTOR

C12 REAR WIPER SW [COMB. SW]

C12 WIPER AND WASHER SW [COMB. SW]

R24 REAR WIPER RELAY

R23 REAR WIPER MOTOR

J3 JUNCTION CONNECTOR

FRONT WIPER RELAY

W3 WIPER MOTOR

Ground points
*Point à terre*
Erdschußpunkt
*Punto de conexión con tierra*

EB = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

EC = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

IH = Located on instrument panel left (LHD)
= *Monté à gauche du tableau de bord (LHD)*
= Angebracht an dem linken Teil der instrumententafel (LHD)
= *Situado al lado derecho del tablero de instrumentos (LHD)*

IH = Located on instrument panel right (RHD)
= *Monté sur le côté droit du tableau de bord (RHD)*
= Angebracht an der richten Seite des instrumentenbretts (RHD)
= *Situado en el lado izquierdo del panel instrumental (RHD)*