Power Source

Starting

Ignition

1 2 3 4 5

F5 A

F5 B

F5 C

F5 D

FUSIBLE LINK BOX

W

W-R (Gasoline)

W (Diesel)

W-R (Gasoline)
W (Diesel)

I14
IGNITION SW
AM1
AM2
ACC
IG1
ST1
IG2
ST2
7 B-W
9 B-R
6 R

STARTER RELAY
S9 E
S10 E

N1
NEUTRAL START SW

B
B (A/T)
B-W (M/T)

B-W
B-W (A/T)
(M/T) B-W
(2RZ-E)

7.5A
STARTER

5 BG 1

B-R

R

I3
IIA
IGNITION COIL

IGNITER

DISTRIBUTOR

2 EB 1
3 EB 1

I6 I , I7 J
IGNITION COIL

IGNITION COIL
I6 I
I7 J

N2
NOISE FILTER

R1
R2
RESISTOR

B-O
B-O (General Ex. Singapore)
B (General, 1RZ LHD)

D1
DISTRIBUTOR

B-O (General Ex. Singapore)
B (General, 1RZ LHD)

To Emission ECU (2-2)
To A/C Amplifier (22-4) (23-5)

C2
CHECK CONNECTOR

B (Europe LHD)
B-O (Ex. Europe LHD)

B (LHD)
B-O (Ex. LHD)

To Tachometer (24-6)
To Emission ECU (2-2)
To A/C Amplifier (22-4) (23-5)

STARTER
S2 G
S3 H BLACK

C3
COLD START INJECTOR

S1
START INJECTOR TIME SW

S9 E , S10 F
STARTER RELAY
(Diesel)

1 BG 1
10 BG 1 (2RZ-E)
1 EC 1 (Ex. 2RZ-E)

(Ex. Europe RHD) W-B

S2 G , S3 H
STARTER

J2
JUNCTION CONNECTOR
17
4
W-B

W (LHD)
W-R
B (A/T)
B-W (M/T)
G

*2 1 C
1 B
4 A
(LHD)

*4
*3

100A
ALT

60A AM1
(LHD)
80A AM1
*1
50A AM1
*2

Ex. *2

F5
FUSIBLE LINK BOX (Diesel)

60A
AM1

30A
AM2

F5
FUSIBLE LINK BOX (Gasoline)

*1 RHD for Europe, and all models Ex. *2
*2 RHD for General, and Australia M/T model w/o conversion package (for Telecom)
*3 Australia w/o conversion package (for Telecom)
*4 All models Ex. *3

B (Gasoline)
B-R (Diesel)

BATTERY

EB
EC

IH
II

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

EB = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

EC = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

IH = Located on instrument panel right (RHD)
= *Monté sur le côté droit du tableau de bord (RHD)*
= Angebracht an der richten Seite des instrumentenbretts (RHD)
= *Situado en el lado izquierdo del panel instrumental (RHD)*

II = Located on instrument panel right (LHD)
= *Monté sur le côté droit du tableau de bord (LHD)*
= Angebracht an der richten Seite des instrumentenbretts (LHD)
= *Situado en lado izquierdo del panel instrumental (LHD)*

II = Located on instrument panel left (RHD)
= *Monté à gauche du tableau de bord (RHD)*
= Angebracht an dem linken Teil der instrumententafel (RHD)
= *Situado al lado derecho del tablero de instrumentos (RHD)*