




CENTER BODY PILLAR INNER (ASSY)**REMOVAL (With the center body pillar outer removed.)****INSTALLATION**

1. Before welding the new parts, temporarily install the center body pillar outer and check the fit.