Power Source

Interior Light (LHD)

1 2 3 4

W

1 1A

7.5A DOME

1

L-Y

13 J9 JUNCTION CONNECTOR 7

L-Y

L-Y

1 BJ1 — R — 1 D15 DOOR COURTESY LIGHT FRONT LH 2 — R-L — 4 BJ1 — R-B

1 BK1 — R-G — 1 D16 DOOR COURTESY LIGHT FRONT RH 2 — R-L — 4 BK1 — R-B

L-Y — 1 I13 IGNITION KEY CYLINDER LIGHT 2 — R-B

L-Y

14 J8 JUNCTION CONNECTOR 7 — 13

L-Y — 7 B C8, C C9 B OPEN DOOR WARNING LIGHT [COMB. METER] 12 C — R-B — 2

(w/ Tachometer)

D14 DIODE 1 — 3 — R-B

R-L

(EUR w/ Door Lock)

R-B — R-B — R-B

D14 DIODE (EUR w/ Door Lock) 1 — 2 — R-B

From Light Reminder Buzzer (19-2) — R-G — R-G

R-W — R-W (Ex. EUR w/ Door Lock) — R-W

R-B

D18 DOOR COURTESY SW FRONT LH 1

D19 DOOR COURTESY SW FRONT RH 1

L-Y

4 BP1 — R — 1 I15 INTERIOR LIGHT FRONT DOOR OFF ON 2 — R-B — 10 BP2 — R-L

R — 2 I16 INTERIOR LIGHT REAR NO. 1 (High Grade Package For Norway) ON OFF DOOR 3 — 1 — R-W — W-B — 12 BP2 — W-B

R — 1 I18 INTERIOR LIGHT REAR DOOR OFF ON 2 — R-W — 2 BP2 — R-L

(High Grade Package For Norway)

R-G — R-G — 1 D14 DIODE 2 — R-L

(High Grade Package For Norway)

R-L — 11 BP2 — R-L — 6 BS1 — R-Y — 1 D17 DOOR COURTESY SW BACK DOOR 2 — W-B — 4 BS1 — W-B

6 BP2 — R-W — R-W — 1 D21 DOOR COURTESY SW SLIDE RH

1 D20 DOOR COURTESY SW SLIDE LH

L-Y — 1 BO1 — R — 1 S18 STEP LIGHT 2 — R-Y — 2 BO1 — R-L

R-L — 1 R9 REAR INTERIOR LIGHT SW 4 — W-B

W-B

F5 FUSIBLE LINK BOX (Gasoline, Diesel)

W — 1 A — FL AM1 60A

BATTERY

B C

J = Located on right rear fender
= *Monté sur l'aile arriere droite*
= Angebracht am rechten hinteren Kotflügel
= *Situado en el guardabarros trasero derecho*

A H J

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

A = Located in fender apron near manifold
= *Monté dons le tablier d'aile près du collecteur*
= Angebracht am Vordern Radkasten nahe am Ansaügkrummer
= *Situado en el faldón del guardabarros cerca del múltiple*

B = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

C = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

H = Located on instrument panel left (LHD)
= *Monté á gauche du tableau de bord (LHD)*
= Angebracht an dem linken Teil der instrumententafel (LHD)
= *Situado al lado derecho del tablero de instrumentos (LHD)*