

E ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points

[LHD: Body]

Seat No. 1 Wire

BL1

Engine Room
Main Wire

BP1

BU1

BU2

Pillar Wire

BI1

Front Door RH Wire

Rear Step RH Wire

BO1

Roof Wire

BS1

BS2

Back Door Wire

Rear Window
No. 2 Wire

BJ

BT2

BJ1

Front Door
LH Wire

BM1

Seat No. 1
Sub Wire

BV1

Seat
No. 1 Wire

Engine Wire

BG1

BP2

Floor No. 2 Wire

BQ1

BR1

Frame Wire

BT1

Rear Window No. 1 Wire

(Swing Out Type)

Roof Wire

BJ

BY1

Back Door No. 1 Wire

Frame Wire

BR1

BX1

Back Door No. 2 Wire