Power Source

Light Reminder

Rear Fog Light

1 2 3 4 5

(Gasoline)

W (*2) (Diesel)

W (Ex. *2) (Diesel)

W (LHD)

W (RHD)

114 IGNITION SW

ACC IG1 ST1 IG2 ST2 AM1 AM2

L-R B-Y

15A RADIO-CIG

10A TURN-GAUGE (LHD)

10A TURN-GAUGE (RHD)

15A TAIL (Ex. Germany) 10A TAIL RH (Germany)

J7 JUNCTION CONNECTOR

15A ECU-B

7.5A DOME

J5 JUNCTION CONNECTOR

REAR FOG LIGHT RELAY

TAILLIGHT RELAY (RHD)

TAILLIGHT RELAY (LHD)

*1 RHD for Europe, and all models Ex. *2
*2 RHD for General, and Australia M/T Model w/o conversion package (for Telecom)
*3 Australia w/o conversion package (for Telecom)
*4 All models Ex. *3

F5 FUSIBLE LINK BOX (Gasoline)

F5 FUSIBLE LINK BOX (Diesel)

60A AM1

100A ALT

60A AM1 (LHD) 80A AM1 *1 50A AM1 *2

Ex. *2

BATTERY

FUSIBLE LINK BOX

F5 A

F5 B

F5 C

L2 LIGHT REMINDER BUZZER

To Door Courtesy SW Front LH (LHD) Front RH (RHD) (9-2) (10-3)

To Light Control SW (8-4)

To Daytime Running Light Relay (Norway, Sweden) To Light Control SW (7-5) (Ex. Norway, Sweden) (7-5)

To Diode (For Rear Fog Light) (Ex. Norway, Sweden) (5-2) (17-2) To Daytime Running Light Relay (Norway, Sweden) (6-2)

To Diode (For Rear Fog Light) (5-2) (18-3)

R6 REAR FOG LIGHT SW

R17 REAR FOG LIGHT LH [REAR COMB. LIGHT LH]

R18 REAR FOG LIGHT RH [REAR COMB. LIGHT RH]

J7 JUNCTION CONNECTOR

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

EB = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

EC = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

IJ = Located on instrument panel right (LHD)
= *Monté sur le côté droit du tableau de bord (LHD)*
= Angebracht an der rechten Seite des instrumentenbretts (LHD)
= *Situado en lado izquierdo del panel instrumental (LHD)*

IJ = Located on instrument panel left (RHD)
= *Monté à gauche du tableau de bord (RHD)*
= Angebracht an dem linken Teil der instrumententafel (RHD)
= *Situado al lado derecho del tablero de instrumentos (RHD)*

BJ = Located on right rear fender
= *Monté sur l'aile arriere droite*
= Angebracht am rechten hinteren Kotflügel
= *Situado en el guardabarros trasero derecho*