Power Source

Turn Signal and Hazard

Horn

1 2 3 4 5

*1 RHD for Europe, and all models Ex. *2
*2 RHD for General, and Australia M/T model w/o conversion package (for Telecom)
*3 Australia w/o conversion package (for Telecom)
*4 All models Ex. *3

I14 IGNITION SW

FUSIBLE LINK BOX

F5 FUSIBLE LINK BOX (Gasoline)

F5 FUSIBLE LINK BOX (Diesel)

BATTERY

TURN SIGNAL LIGHT FRONT LH, RH

(Ex. Thailand) F10, F11

(Thailand) T5, T6

10A TURN-GAUGE (LHD)

10A TURN-GAUGE (RHD)

J5 JUNCTION CONNECTOR

H1 HAZARD SW

T2 TURN SIGNAL FLASHER

J1 JUNCTION CONNECTOR

C18 TURN SIGNAL SW [COMB. SW]

15A HAZ-HORN

J9 JUNCTION CONNECTOR

INDICATOR LIGHT [COMB. METER]

(w/o Tachometer) C8

(w/ Tachometer) C10

(w/o Tachometer) C10

(w/ Tachometer) C11

HORN RELAY

C13 HORN SW [COMB. SW]

H11 HORN

R17 REAR TURN SIGNAL LIGHT [REAR COMB. LIGHT LH]

R18 REAR TURN SIGNAL LIGHT [REAR COMB. LIGHT RH]

F10, T5 TURN SIGNAL LIGHT FRONT LH

F11, T6 TURN SIGNAL LIGHT FRONT RH

J7 JUNCTION CONNECTOR

J3 JUNCTION CONNECTOR

BJ = Located on right rear fender
= *Monté sur l'aile arrière droite*
= Angebracht am rechten hinteren Kotflügel
= *Situado en el guardabarros trasero derecho*

IH, IJ, BJ

Ground points
Point à terre
Erdschußpunkt
Punto de conexión con tierra

EB = Located on engine block
= *Monté sur le bloc-moteur*
= Angebracht auf dem Motor
= *Situado en el bloque motor*

EC = Located on left side member
= *Monté sur le côté gauche du longeron*
= Angebracht an der linken Seite der Kreuzstrebe
= *Situado en el lado izquierdo del travesaño*

IH = Located on instrument panel left (LHD)
= *Monté à gauche du tableau de bord (LHD)*
= Angebracht an dem linken Teil der instrumententafel (LHD)
= *Situado al lado derecho del tablero de instrumentos (LHD)*

IH = Located on instrument panel right (RHD)
= *Monté sur le côté droit du tableau de bord (RHD)*
= Angebracht an der richten Seite des instrumentenbretts (RHD)
= *Situado en el lado izquierdo del panel instrumental (RHD)*

IJ = Located on instrument panel right (LHD)
= *Monté sur le côté droit du tableau de bord (LHD)*
= Angebracht an der richten Seite des instrumentenbretts (LHD)
= *Situado en lado izquierdo del panel instrumental (LHD)*

IJ = Located on instrument panel left (RHD)
= *Monté à gauche du tableau de bord (RHD)*
= Angebracht an dem linken Teil der instrumententafel (RHD)
= *Situado al lado derecho del tablero de instrumentos (RHD)*