

## D RELAY LOCATIONS

② : R/B No.2 (LHD)

○ : J/B No.2 (LHD)

Instrument Panel Center (See Page 28)

\*1 : 10A SRS or 10A RR CIG2  
 \*2 : 10A IG2 or 10A RR CIG1  
 \*3 : 5A ECU-B or 15A RR FOG  
 \*4 : 15A RADIO & CIG

