

PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number	
A 1	A/C Magnetic Clutch	90980-11271	B 8	Back Door Junction SW LH	90980-10355	
A 3	Alternator	90980-11349	B 9	Back Door Junction SW RH		
A 4	Alternator (LHD)	90980-09373	B10	Back Door Junction SW RH		
	Alternator (RHD)	90980-09212	B11	Back Door Courtesy SW (Except LHD 2RZ-E)		
A 5	A/C Amplifier (Diesel Dual Type)	90980-10848			Back Door Courtesy SW (LHD 2RZ-E)	90980-10437
	A/C Amplifier (Diesel Single Type)	90980-10045	B12	Back Door Lock Motor	90980-11292	
	A/C Amplifier (Gasoline Dual Type)	90980-10819	C 1	Check Connector (LHD 1RZ,2RZ)	90980-10179	
	A/C Amplifier (Gasoline Single Type)	90980-10801			Check Connector (LHD 2RZ-E)	90980-10778
A 6	A/C Circuit Breaker	90980-10185			Check Connector (RHD 1RZ)	90980-10179
A 8	A/C Cut Relay	90980-10142			Check Connector (RHD Except 1RZ)	90980-11195
A10	A/C Magnetic Clutch Relay	90980-10171	C 5	Cigarette Lighter	90980-10760	
A11	A/C SW	90980-11280	C 6	Cigarette Lighter Illumination	90980-11148	
A12	A/C Volume SW	90980-10414	C 7	Clock (LHD)	90980-10631	
A13	Ashtray Illumination	90980-10355			Clock (RHD)	90980-10789
A15	A/C Triple Pressure SW (A/C Dual and Single Pressure SW) or A/C Dual Pressure SW (Dual Type)	90980-10943	C 8	Combination Meter	90980-11113	
	A/C Triple Pressure SW (A/C Dual and Single Pressure SW) or A/C Dual Pressure SW (Single Type)	90980-10617	C 9	Combination Meter	90980-11116	
A16	A/T Fluid Pressure SW	90980-11282	C10	Combination Meter	90980-11115	
A17	A/C Condenser Fan Relay No.1	90980-10171	C11	Combination Meter	90980-11114	
A18	A/C Condenser Fan Relay No.2	90980-10713	C12	Combination SW (China)	90980-11432	
A19	A/C Thermistor	90980-10825			Combination SW (Except China)	90980-11594
A20	A/C Condenser Fan Motor	90980-10990	C13	Combination SW (RHD)	90980-11671	
A21	A/C Condenser Fan Motor and Resistor				Combination SW (China)	90980-11433
A22	ABS Speed Sensor Front LH	90980-11075			Combination SW (LHD Except China)	90980-11672
A23	ABS Speed Sensor Front RH		C14	Check Connector	90980-11195	
A24	ABS ECU	90980-11390	C15	Cigarette Lighter and Illumination	90980-11090	
A25	ABS ECU	90980-11424	D 3	Defogger SW	90980-10797	
A26	Airbag Sensor Assembly (LHD)	90980-11681	D 8	Diode (Glow Plug)	90980-10962	
	Airbag Sensor Assembly (RHD)	90980-11683	D10	Door Lock Control Relay	90980-10801	
A27	Airbag Squib (Front Passenger Airbag Assembly)	90980-11884	D18	Door Courtesy SW Front LH (LHD)	90980-11737	
A28	Airbag Squib (Steering Wheel Pad)	90980-10850			Door Courtesy SW Front LH (RHD)	90980-10870
A30	ABS Actuator	90980-10891	D19	Door Courtesy SW Front RH (LHD)	90980-11737	
A31	ABS Actuator	90980-11413			Door Courtesy SW Front RH (RHD)	90980-10870
A32	ABS Speed Sensor Rear LH	90980-11467	D27	Door Lock Motor Front LH	90980-11292	
A33	ABS Speed Sensor Rear RH		D28	Door Lock Motor Front RH		
B 1	Back-Up Light SW	90980-11250	D36	Diode (O/D)	90980-10962	
B 3	Blower Motor	90980-10214	D38	Door Key Lock and Unlock SW LH	90980-11245	
B 4	Blower Resistor	90980-10171	D39	Door Key Lock and Unlock SW RH		
B 5	Brake Fluid Level Warning SW	90980-10214	D40	Door Lock Control SW (Back Door)	90980-10801	
B 6	Buckle SW (Driver's Side)	90980-10437	D41	Door Courtesy Light Front LH	90980-10121	
B 7	Back Door Junction SW LH	90980-10355	D42	Door Courtesy Light Front RH		
			E 1	EFI Water Temp. Sensor	90980-10737	
			E 2	Engine Oil Level SW	90980-10532	

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
E 3	Emission ECU (1RZ)	90980-10797	H16	Headlight Beam Level Control SW	90980-11280
	Emission ECU (2RZ)	90980-10801	H17	Headlight Beam Level Control Actuator LH	90980-11016
E 4	Engine ECU (M/T),Engine and ECT ECU (A/T)	90980-11391	H18	Headlight Beam Level Control Actuator RH	
E 5	Engine ECU (M/T),Engine and ECT ECU (A/T)	90980-11424	I 1	IIA	90980-11038
			I 2	IIA	90980-11037
E 6	Engine ECU (M/T),Engine and ECT ECU (A/T)	90980-11390	I 3	IIA (1RZ)	90980-11038
				IIA (2RZ)	90980-11037
E 7	ECT Solenoid	90980-10919	I 8	Injector No. 1	90980-11285
E 8	Emission ECU	90980-11391	I 9	Injector No. 2	
E 9	Emission ECU	90980-11390	I10	Injector No. 3	
E10	ECT Pattern Select SW	90980-10601	I11	Injector No. 4	
F 1	Fuel Cut Solenoid, Outer Vent Control Valve and Choke Heater	90980-10171	I12	Intake Air Temp. Sensor	90980-11163
F 2	Fuel Cut Solenoid and Pick-Up Sensor or Fuel Cut Solenoid and Timing Control Valve	90980-11157	I14	Ignition SW	90980-10862
F 3	Fuel Filter Warning SW	90980-11255	I16	Interior Light Rear No.1 (Except Fluorescent Light Type)	90980-10121
F 4	Fuel Heater	90980-10928		Interior Light Rear No.1 (Fluorescent Light Type)	90980-10908
F10	Front Clearance Light and Turn Signal Light LH	90980-10216	I18	Interior Light Rear (Except Fluorescent Light Type)	90980-10121
F11	Front Clearance Light and Turn Signal Light RH			Interior Light Rear (Fluorescent Light Type)	90980-10908
F12	Fuel Pump	90980-11248	I19	Ignition Key Cylinder Light	90980-10214
F13	Fuel Sender	90980-10365	J 2	Junction Connector	90980-10803
F15	Front Fog Light LH	90980-11019	J 3	Junction Connector	
F16	Front Fog Light RH		J 4	Junction Connector	
F19	Fusible Link Box	—	J 5	Junction Connector	
F21	Front Turn Signal Light LH	90980-11075	J 7	Junction Connector	90980-11661
F22	Front Turn Signal Light RH		J 8	Junction Connector	
F23	Front Clearance Light LH	90980-11156	J 9	Junction Connector	90980-10803
F24	Front Clearance Light RH		J11	Junction Connector	
F25	Front Fog Light SW	90980-10799	J12	Junction Connector	
F27	Fusible Link Block	82620-28080	J13	Junction Connector	
G 1	Glow Plug	90980-09320	J15	Junction Connector	90980-10875
G 8	Glow Plug Relay	90980-11569	J16	Junction Connector	
H 1	Hazard SW	90980-10801	J17	Junction Connector	90980-10801
H 4	Heater Blower SW	90980-10463	J18	Junction Connector	90980-10875
H 7	Headlight LH	90980-11314	J19	Junction Connector	90980-10803
H 8	Headlight RH		J21	Junction Connector	90980-11542
H11	Horn LH	90980-10619	J22	Junction Connector	
H13	High Mounted Stop Light (LHD)	90980-10860	J23	Junction Connector	90980-11542
	High Mounted Stop Light (RHD Back Door w/ Stop Light Type)	90980-10355	J24	Junction Connector	
H13	High Mounted Stop Light (RHD Back Door w/o Stop Light Type)	90980-10860	J25	Junction Connector	90980-11661
H14	Heated Oxygen Sensor	90980-11028	J26	Junction Connector	90980-11661
H15	Horn RH	90980-11235			

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

一般 HIACE (EWD365F)

PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
J27	Junction Connector	90980-10803	R 8	Rear Heater SW (Front)	90980-10996
J28	Junction Connector		R 9	Rear Interior Light SW	90980-10601
J29	Junction Connector		R10	Rear Magnetic Valve	90980-10860
J31	Junction Connector	90980-11661	R11	Rheostat or Short Connector	90980-10171
J32	Junction Connector		R12	Rear A/C SW	90980-10322
J33	Junction Connector	90980-10803	R13	Rear Blower Motor LH	90980-10214
J34	Junction Connector	90980-10897	R14	Rear Blower Motor RH	
J35	Junction Connector	90980-10803	R15	Rear Blower Resistor	90980-10216
L 3	License Plate Light (LHD)	90980-10355	R16	Rear Blower SW	90980-10171
	License Plate Light (RHD Back Door w/ Stop Light Type)		R17	Rear Combination Light LH (LHD,RHD Back Door w/o Stop Light Type)	90980-10173
	License Plate Light (RHD Back Door w/o Stop Light Type)	90980-10859		Rear Combination Light LH (RHD Back Door w/ Stop Light Type)	90980-11011
L 4	Luggage Compartment Light	90980-10121	R18	Rear Combination Light RH (LHD,RHD Back Door w/o Stop Light Type)	90980-10173
N 1	Neutral Start SW , Back-Up Light SW and A/T Indicator Light SW	90980-11332		Rear Combination Light RH (RHD Back Door w/ Stop Light Type)	90980-11011
N 2	Noise Filter (Ignition System)	90980-10179	R19	Rear Heater Blower Motor	90980-11795
O 1	O/D Main SW	90980-10502	R20	Rear Heater Blower SW	90980-10216
O 3	Oil Pressure SW (Diesel)	99146-12010	R21	Rear Heater SW (Rear)	90980-10996
	Oil Pressure SW (Gasoline)	90980-11363	R22	Rear Washer Motor	90980-10214
O 4	O/D ECU	90980-10797	R23	Rear Wiper Motor	90980-10504
P 1	Parking Brake SW (LHD)	90980-10182	R24	Rear Wiper Relay	90980-10797
	Parking Brake SW (RHD)	—	R26	Rear A/C Thermistor	90980-10825
P 3	Pre-Heating Timer (LHD 5L,CIS,Turkey)	90980-10803	R27	Rear A/C Volume SW	90980-10039
	Pre-Heating Timer (LHD Except 5L,CIS and Turkey)	90980-10799	R28	Rear Window Defogger	—
	Pre-Heating Timer (RHD 3L Singapore)	90980-10803	R29	Rear Window Defogger	
	Pre-Heating Timer (RHD Except 3L Singapore)	90980-10799	R30	Rear Window Defogger LH	
P 5	Power Window Control SW Front LH	90980-10509	R31	Rear Window Defogger LH	
P 6	Power Window Control SW Front RH	90980-10789	R32	Rear Window Defogger RH	
P 7	Power Window Master SW (LHD)	90980-10997	R33	Rear Window Defogger RH	
	Power Window Master SW (RHD)	90980-10803	R34	Radio and Player	90980-10996
P 8	Power Window Motor Front LH	90980-11248	R35	Rear Combination Light LH No.2	90980-10908
P 9	Power Window Motor Front RH (LHD)		R36	Rear Combination Light RH No.2	
	Power Window Motor Front RH (RHD)	90980-11290	R37	Remote Control Mirror LH	90980-11182
P10	Pick-Up Sensor	90980-11162	R38	Remote Control Mirror RH	
P11	Power Outlet (Front)	90980-10859	R39	Remote Control Mirror SW	90980-11450
P12	Power Outlet (Rear)		S 2	Starter	—
R 1	Radiator Fluid Level Sensor (Diesel)	90980-11003	S 3	Starter (Diesel)	90980-11184
	Radiator Fluid Level Sensor (Gasoline)	90980-10216		Starter (Gasoline)	90980-11400
R 3	Radio and Player	90980-10997	S 7	Speaker Front LH	90980-10935
R 5	Rear Blower Motor Relay	90980-10713	S 8	Speaker Front RH	
R 6	Rear Fog Light SW or Short Connector	90980-11533	S 9	Starter Relay	82602-26010
			S11	Stop Light SW	90980-11118

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
S17	Step Light	90980-10121	U 1	Unlock Warning Relay	90980-10797
S19	Speed Sensor	90980-11143	V 1	Vacuum Sensor	90980-10845
S20	Slide Door Courtesy SW LH	90980-10870	V 2	Vacuum SW (Emission Control)	90980-11278
S21	Slide Door Courtesy SW RH		V 7	Vacuum SW	90980-11252
S22	Slide Door Junction SW LH	90980-11013	V 8	VSV (A/C Idle-Up) (2RZ-E)	90980-11149
S23	Slide Door Junction SW RH			VSV (A/C Idle-Up) (Except 2RZ-E)	90980-10214
S26	Short Connector	90980-10799	V 9	VSV (Air Bypass)	
S27	Short Connector	90980-10798	V11	Variable Resistor	90980-10902
S28	Speaker Rear LH	90980-10825	V12	VSV(EGR)	90980-11162
S29	Speaker Rear RH		W 1	Water Temp. Sender	90980-11428
S30	Speed Sensor (ECT)	90980-10923	W 2	Water Temp. Sensor (Glow)	90980-10737
T 1	Throttle Position Sensor (2RZ-E)	90980-10711	W 3	Wiper Motor	90980-10171
	Throttle Position Sensor (5L)	90980-11016	W 5	Washer Motor	90980-11250
T 2	Turn Signal Flasher	90980-10704			

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.