

## ABBREVIATIONS USED IN THIS MANUAL

A/C	Air Conditioner
Approx.	Approximation
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
CB	Circuit Breaker
ECT	Electronic Controlled Transmission
ECU	Electronic Controlled Unit
EGR	Exhaust Gas Recirculation
Ex.	Except
FL	Fusible Link
IG	Ignition
LH	Left-Hand
LHD	Left-Hand Drive
LSD	Limited Slip Differential
LSP & BV	Load Sensing Proportioning and By-Pass Valve
LSPV	Load Sensing Proportioning Valve
MP	Multipurpose
M/T, MT	Manual Transmission
OD, O/D	Overdrive
PS	Power Steering
RH	Right-Hand
RHD	Right-Hand Drive
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
T/M	Transmission
VSV	Vacuum Switching Valve
w/	With
w/o	Without
2WD	2 Wheel Drive Vehicles (4 x 2)
4WD	4 Wheel Drive Vehicles (4 x 4)

