

AUTOMATIC TRANSMISSION (A45DE)

HOW TO PROCEED WITH TROUBLESHOOTING

DISNE-03

Items inside **▮** are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations.

