


# TT Terminal Circuit

## CIRCUIT DESCRIPTION

Checks of the Engine & ECT ECU input and output signals related to the throttle position sensor, brakes, shift range and other circuits can be done by measuring the voltages at terminal TT of the check connector.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

- 1 Check harness and connector between body ground and check connector, check connector and Engine & ECT ECU (See page IN-30).

NG Repair or replace the harness or connector.

OK

Check and replace the Engine & ECT ECU (See page IN-30).