


TERMINALS OF ECU



No.	Symbol	Terminal Name
A	–	Electrical Connector Check Mechanism
B	–	Electrical Connector Check Mechanism
2	P–	Squib (Passenger)
3	P+	Squib (Passenger)
5	LA	SRS Warning Light
6	D–	Squib (Driver)
7	D+	Squib (Driver)
8	Tc	Diagnosis
9	E2	Ground
10	E1	Ground
15	IG2	Power Source (IGN Fuse)
16	ACC	Power Source (CIG Fuse)