

INSTALLATION

Installation is in the reverse order of removal (See page BR-20).

HINT:

After installation, fill the brake reservoir with brake fluid, bleed brake system (Refer Pub. No. RM156E on BR section) and check for leaks.