

## INSTALLATION

Install in the reverse order of removal (See page CL-2).

HINT:

After installation, bleed the clutch system.