



## ADJUSTMENT

### ADJUST FOG LIGHT AIM

The fog light aim can be adjusted by moving the A-bolt in the vertical direction.