



TIRE AND WHEEL INSPECTION

SA1GT-01

INSPECT TIRE

- (a) Check the tires for wear and proper inflation pressure.
Cold tire inflation pressure: [See page SS-9](#)

- (b) Check the tire runout.

Tire runout: 1.0 mm (0.039 in.) or less